




Ningbo Greenis Home Appliances Co.,LTD
 Email: love@greenis.com.cn
 Web: www.greenis.com
 greenis.business.page



USER MANUAL FOR AUTOMATIC SOAP DISPENSER

Please read the manual before using and keep the manual where it is accessible

List of Components



1

Features



Durable Motor



Thick foam



1/4 sec Instant
 Dispensing*



Splash Resistance



Refillable tank*



Batteries lasts
 up to 9 months*

2


Installation Steps



Twist anticlockwise to release the Battery Chamber Cover.



Do insert 4 AA batteries properly. Follow the symbols showing the correct way to position the positive (+) and negative (-) ends of the batteries.



Align the Unlock symbol shown on the battery cover with the Triangle symbol shown on the dispenser body.



Twist clockwise the Battery Chamber Cover until the Lock symbol signs with Triangle symbol.

3

Installation Steps



Twist the Soap Tank Cover anticlockwise to remove it. Remove the Silicone Stopper. Dilute average sanitizer with water following a ratio of 1:3 or 1:4 and gently shake the Soap Tank until properly mixed. Pour the mixture into the Soap Tank.



Place the Dispenser onto the Soap Tank and gently twist it anticlockwise to fasten.

3

How to Use



1. Tap the Power Button/Indicator to start.



2. It is recommended that you should rinse your hands first.



3. Reach your hands within the Detection Area to receive foam.



4. Rub your fingers and palms thoroughly.



5. Rinse your hands with water and wipe dry.

Tips: The soap dispenser will automatically enter stand-by mode when it is not in use for some time, which eliminates the need to power it off.

4

Status	Indicator
Powered on	Illuminates blue for 2 sec.
Powered off	Blinking red slowly 2 times until dimmed
Low Battery	Blinking red quickly 3 times after detection

Footnotes:

- Following the sensor's detection of the object (hands), it will take a maximum of 0.25 sec for the foam to be dispensed.
- Non-foaming sanitizer diluted with water following a ratio of 1:3 or 1:4, then fill the mixture into the soap tank.
- Calculated based on the use rate: 15 times per day, in a 24/7 use mode.

Care and Maintenance

- Dampen a towel to wipe clean the surface of the product.
- Remove the batteries to avoid leak risk if you won't be using the product for some time.

Use Precautions

- To avoid short-circuit hazard, do not immerse the product in water or clean it with water.
- Do not tilt the soap tank while installing the product or refilling soap. Minor leak of liquid is deemed normal, simply wipe it clean and proceed.
- Place the product in a dry and cool place and avoid direct sunlight and heat sour.

5

Troubleshooting

Troubles	Possible Causes	Solutions
Does not power on	Batteries placed in the wrong way	Follow +/- symbols to place batteries properly.
Indicator does not illuminate	1. Dispenser not powered on. 2. Batteries placed in the wrong way.	1. Tap power switch button to power on. 2. Remove batteries and replace them.
Foam spout does not produce foam	1. Soap used up. 2. Low battery.	1. Refill soap 2. Replace batteries
Indicator blinking red quickly	Sensor part (black) blocked by foam.	Power off the dispenser and wipe clean the sensor. Power on again.

6

Specs

product name	automatic foaming soap dispenser
Material (used mainly)	ABS
Rated voltage	6V
Battery	AA alkaline 1.5V
Operating temperature	5°C~40°C
Operating humidity	0%~85% RH

7